




# PoUSB12C

User's manual

v1.0



**Please read the following notes**

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice.
2. PoLabs does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of PoLabs products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of PoLabs or others. PoLabs claims the copyright of, and retains the rights to, all material (software, documents, etc.) contained in this release. You may copy and distribute the entire release in its original state, but must not copy individual items within the release other than for backup purposes.
3. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of the products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. PoLabs assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
4. PoLabs has used reasonable care in preparing the information included in this document, but PoLabs does not warrant that such information is error free. PoLabs assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
5. PoLabs devices may be used in equipment that does not impose a threat to human life in case of the malfunctioning, such as: computer interfaces, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment, and industrial robots.
6. Measures such as fail-safe function and redundant design should be taken to ensure reliability and safety when PoLabs devices are used for or in connection with equipment that requires higher reliability, for example: traffic control systems, anti-disaster systems, anticrime systems, safety equipment, medical equipment not specifically designed for life support, and other similar applications.
7. PoLabs devices shall not be used for or in connection with equipment that requires an extremely high level of reliability and safety, as for example: aircraft systems, aerospace equipment, nuclear reactor control systems, medical equipment or systems for life support (e.g. artificial life support devices or systems), and any other applications or purposes that pose a direct threat to human life.
8. You should use the PoLabs products described in this document within the range specified by PoLabs, especially with respect to the maximum rating, operating supply voltage range and other product characteristics. PoLabs shall have no liability for malfunctions or damages arising out of the use of PoLabs products beyond such specified ranges.
9. Although PoLabs endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, PoLabs products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a PoLabs product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures.
10. Usage: the software in this release is for use only with PoLabs products or with data collected using PoLabs products.
11. Fitness for purpose: no two applications are the same, so PoLabs cannot guarantee that its equipment or software is suitable for a given application. It is therefore the user's responsibility to ensure that the product is suitable for the user's application.
12. Viruses: this software was continuously monitored for viruses during production; however, the user is responsible for virus checking the software once it is installed.
13. Upgrades: we provide upgrades, free of charge, from our web site at [www.poscope.com](http://www.poscope.com). We reserve the right to charge for updates or replacements sent out on physical media.
14. Please contact a PoLabs support for details as to environmental matters such as the environmental compatibility of each PoLabs product. Please use PoLabs products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. PoLabs assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
15. Please contact a PoLabs support at [support@poscope.com](mailto:support@poscope.com) if you have any questions regarding the information contained in this document or PoLabs products, or if you have any other inquiries.
16. The licensee agrees to allow access to this software only to persons who have been informed of and agree to abide by these conditions.
17. Trademarks: Windows is a registered trademark of Microsoft Corporation. PoKeys, PoKeys55, PoKeys56U, PoKeys56E, PoScope, PoLabs and others are internationally registered trademarks.

# Contents

- 1 Introduction..... 4
- 2 Connectors and pinout..... 4
- 3 Usage examples..... 5
- 4 Grant of license ..... 6
  - 4.1.1 Access ..... 6
  - 4.1.2 Usage ..... 6
  - 4.1.3 Copyright ..... 6
  - 4.1.4 Liability ..... 6
  - 4.1.5 Fitness for purpose..... 6
  - 4.1.6 Mission Critical applications..... 6
  - 4.1.7 Errors ..... 6
  - 4.1.8 Support..... 6
  - 4.1.9 Upgrades ..... 6
  - 4.1.10 Trademarks..... 6

## 1 Introduction


The PoUSB12C is a USB 2.0 to RS-232 (UART) bridge converter which is simple, cost effective, very small and easy to use. It uses a USB-C type connector to connect to your PC and is based on the CP2102 Bridge from Silicon Labs. It provides the user with multi baud rate serial data and access to USB control signals in a convenient 8 pin 2,54 mm (0.1") pitch package. The PoUSB12C is ideal for prototype or production.

The converter automatically manages the requests from USB host and commands for controlling the UART functions which simplifies the development effort and firmware. PoUSB12C also supports the RS485 standard and has an additional pin for transmit/receive (driver/receive enable) selection. To modify the device and its functionality Simplicity Studio [software](#) can be downloaded and used.

### Main Features:

- USB 2.0 compliant full-speed device (12Mbps maximum speed).
- Xon/Xoff handshaking supported (300bps to 3Mbps).
- UART supports 5-8 bit data, 1-2 Stop bits, odd/even and no parity.
- Integrated EEPROM for Vendor ID, product ID, serial and release number.
- On-chip 3.3V regulator available with power on reset circuit.
- USB powered.
- TX and RX signal levels are between 0V and 3.3V but 5V logic compatible.
- Temperature range: -40 to +85 °C.
- Small size: 19mm x 11mm x 4mm.
- Virtual COM port drivers for Windows, Linux and MACOS.
- Simplicity Studio [software](#) for customization

## 2 Connectors and pinout




## Pin description

<b>5V</b>	Supply pin for 5V power from USB
<b>3V3</b>	Regulated 3.3V power supply from IC (100mA max)
<b>GND</b>	Ground
<b>TX (TXD)</b>	Digital Output. Asynchronous data output (UART Transmit)
<b>RX (RXD)</b>	Digital Input. Asynchronous data input (UART Receive)
<b>RTS</b>	Digital Output. Ready To Send control output (active low).
<b>CTS</b>	Digital Input. Clear To Send control input (active low).
<b>RS485 (485)</b>	Digital Output. RS485 control signal.


## 3 Usage examples

PoUSB12 makes USB to Serial interface very simple, so you can easily create USB to RS-232 converters, USB to RS-422/RS-485 converters, upgrade legacy RS232 devices, make PDA and cellphone USB interface cables, barcode readers, POS terminals, etc. In any application, make sure the TX and RX lines from the PoUSB12 are crossed over to the attached peripheral. That is, the TX from the PoUSB12 connects to the RX of the target and the RX from the PoUSB12 connects to the TX of the target device. Note: the TX and RX signal levels are between 0.0 Volts and 3.3 Volts and they are 5V logic compatible.

The RS485 pin is an optional control pin that can be connected to the DE and RE inputs of the transceiver. When configured for RS485 mode, the pin is asserted during UART data transmission. The RS485 pin is active-high by default and is also configurable for active low mode using Xpress Configurator.



## 4 Mechanical dimensions



## 5 Grant of license

The material contained in this release is licensed, not sold. PoLabs grants a license to the person who installs this software, subject to the conditions listed below.

### 5.1.1 Access

The licensee agrees to allow access to this software only to persons who have been informed of and agree to abide by these conditions.

### 5.1.2 Usage

The software in this release is for use only with PoLabs products or with data collected using PoLabs products.

### 5.1.3 Copyright

PoLabs claims the copyright of, and retains the rights to, all material (software, documents etc) contained in this release. You may copy and distribute the entire release in its original state, but must not copy individual items within the release other than for backup purposes.

### 5.1.4 Liability

PoLabs and its agents shall not be liable for any loss or damage, howsoever caused, related to the use of PoLabs equipment or software, unless excluded by statute.

### 5.1.5 Fitness for purpose

No two applications are the same, so PoLabs cannot guarantee that its equipment or software is suitable for a given application. It is therefore the user's responsibility to ensure that the product is suitable for the user's application.

### 5.1.6 Mission Critical applications

Because the software runs on a computer that may be running other software products, and may be subject to interference from these other products, this license specifically excludes usage in 'mission critical' applications, for example life support systems.

### 5.1.7 Errors

This manual was continuously monitored for errors during production; however, the user is responsible for error checking the manual once it is used.

### 5.1.8 Support

There could be errors in these manuals, but if you found some, please contact our technical support staff, who will try to fix the problem within a reasonable time.

### 5.1.9 Upgrades

We provide upgrades, free of charge, from our web site at [www.PoLabs.com](http://www.PoLabs.com). We reserve the right to charge for updates or replacements sent out on physical media.

### 5.1.10 Trademarks

Windows is a registered trademark of Microsoft Corporation. PoKeys, PoKeys55, PoKeys56U, PoKeys56E, PoKeys57U, PoKeys57E, PoKeys57CNC, PoScope, PoLabs, PoExtBus, PoExtBus Smart, PoRelay8, PlasmaSens and others are internationally registered trademarks.

Support:

[www.PoLabs.com](http://www.PoLabs.com)